

The instructions for software update download and micro-SD card format are as follows:

1. Download the .bin file onto your computer
2. Remove the micro-SD card from the device, insert it in your computer and copy the attached file onto the card (file must be copied in main/root directory - not in any folders). **NOTE: if you have any files on your card, please transfer them to your computer now, because they will be deleted after update process is finished.**
3. Insert the micro-SD card back into the unit and turn the camera ON
4. Allow the update to run (LED lights will be flashing on and off for some time and after update is done the camera will turn on).
5. When unit turns ON, press and hold IR button for 2sec – menu will appear – scroll down/up the menu with the long Zoom/Image button until you see Format – short press IR button to select it, then scroll down to OK with Zoom/Image button and short press IR button to format the card.

If you have any questions, please call us at 1-972-722-1100 or e-mail us at info@lunaoptics.com