

LN-G3-M QUICK START GUIDE


1. INSTALLING BATTERIES:

- Unscrew battery compartment cover
- Insert 2xCR123A batteries as shown on diagram (+ side going in first)
- Replace battery compartment cover



2. POWERING ON/OFF:

- Single short-press on POWER button powers the unit ON
- Single long-press on POWER button powers the unit OFF




3. FOCUSING MONOCULAR:

- Rotate front objective lens in either direction until the image gets better
- Now rotate ocular lens also in either direction until best image
- Repeat above steps if necessary
- After sharp image is achieved, going forward only rotate front objective lens for distance adjustment




4. TURNING INFRARED ILLUMINATOR ON/OFF:

- Short-press on POWER button turns the IR illuminator ON at Level-1
- Then each short-press on the same button increases IR power to Level-2 & Level-3
- After Level-3 the next short-press turns the IR illuminator OFF




5. TAKING PICTURES AND RECORDING VIDEOS:

- Short-press on CAMERA button starts video recording or takes a still image
- Long-press on CAMERA button selects between Video, Photo & Playback



6. ADJUSTING BRIGHTNESS AND IMAGE COLOR:

- Short-press on IMAGE button adjusts display brightness
- Long-press on IMAGE button selects image color



7. ADJUSTING IMAGE MAGNIFICATION:

- Rotate SUPER CONTROLLER clockwise to increase image magnification
- Rotate SUPER CONTROLLER counter-clockwise to decrease image magnification

